



Leading Conversion Technology for Power Resilience


e-one 3 - 48/230

User Manual V1.3

BEYOND THE INVERTER

THE NEW GENERATION OF POWER CONVERTERS

- EASY TO INSTALL
- COMPACT DESIGN
- HIGH EFFICIENCY
- WIDE OPERATING TEMPERATURE RANGE
- SHORT DEPTH ALLOWS 300 MM RACK INTEGRATION



Copyright © 2021. Construction electroniques & telecommunications S.A.
All rights reserved. The contents in document are subject to change without notice.
The products presented are protected by several international patents and trademarks.
Address: CE+T S.a, Rue du Charbonnage 12, B 4020 Wandre, Belgium
www.cet-power.com - info@cet-power.com

 www.cet-power.com

 Belgium, China, India, Luxembourg, Malaysia, Russia, United Kingdom, United States, Australia & Germany

Table of Contents

| | |
|--|----|
| 1. Introduction to CE+T | 5 |
| 2. Abbreviations | 6 |
| 3. Warranty and Safety Conditions | 7 |
| 3.1 Handling..... | 8 |
| 3.2 Surge and transients | 8 |
| 3.3 Other..... | 8 |
| 4. Description | 9 |
| 4.1 Typical load | 9 |
| 4.2 Module Specifications: | 9 |
| 5. Installation | 11 |
| 5.1 e-one dimensions | 11 |
| 5.1.1 Mounting Kit..... | 11 |
| 5.1.2 19-Inch Sub-rack | 12 |
| 5.2 Wiring | 13 |
| 5.2.1 REG Model - Termination Details | 13 |
| 5.2.2 DC Input connection | 14 |
| 5.2.3 AC Output distribution | 14 |
| 5.2.4 Replacing Fuse..... | 15 |
| 5.2.5 Grounding | 16 |
| 5.2.6 Remote Monitoring and Control | 16 |
| 6. Getting started | 17 |
| 6.1 Starting procedure | 17 |
| 6.2 LED indication- Alarm status | 17 |
| 7. Finishing | 18 |
| 8. Disassembly & Disposal | 19 |
| 8.1 Disassembly..... | 19 |
| 8.2 Disposal | 19 |
| 9. Commissioning | 20 |
| 9.1 Check list..... | 20 |
| 10. Trouble shooting and Defective modules | 21 |
| 10.1 Trouble shooting..... | 21 |
| 10.2 Defective Modules..... | 21 |
| 11. Service and Maintenance Task | 22 |
| 11.1 Service..... | 22 |
| 11.2 Maintenance Task | 22 |
| 12. Appendix..... | 23 |
| 12.1 e-one 3 - 48/230 - Wiring diagram..... | 23 |

| | |
|--|----|
| 12.2 e-one 3 - 48/230 - Dimensions | 24 |
| 12.2.1 Module..... | 24 |
| 12.2.2 19-Inch Sub-rack..... | 24 |

Release Note:

| Version | Release date (DD/MM/YYYY) | Modified page number | Modifications |
|----------------|--------------------------------------|---------------------------------|------------------------------|
| 1.0 | 30/11/2018 | - | First release of the Manual. |
| 1.1 | 30/01/2019 | 8 | Part number |
| 1.2 | 28/08/2020 | 11 | 19-Inch Sub-rack |
| 1.3 | 21/12/2021 | 23 | Updated schematic |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

1. Introduction to CE+T

CE+T Power designs, manufactures, and markets a range of products for industrial operators, with mission critical applications, who are not satisfied with existing AC backup system performances and related maintenance costs.

Our product is an innovative AC backup solution that unlike most UPS's available.

- Maximizes the operator's applications uptime;
- Operates with lowest OPEX;
- Provides best protection to disturbances;
- Optimizes footprint.

Our systems are:

- Modular
- Truly redundant
- Highly efficient
- Maintenance free
- Battery friendly

CE+T power puts 60+ years expertise in power conversion together with worldwide presence to provide customized solutions and extended service 24/7 - 365 days per year.

2. Abbreviations

| | |
|-----|--|
| AC | Alternating current |
| DC | Direct current |
| DSP | Digital Signal Processor |
| ESD | Electro Static Discharge |
| MET | Main Earth Terminal |
| N | Neutral |
| PCB | Printed Circuit Board |
| PE | Protective Earth (also called Main Protective Conductor) |
| REG | Regular |
| USB | Universal Serial Bus |

3. Warranty and Safety Conditions*

WARNING:

The electronics in the power supply system are designed for indoor, clean environment.

When installed in dusty and/or corrosive environment, outdoor or indoor, it is important to:

- Install an appropriate filter on the enclosure door, or on the room's air control system
- Keep the enclosure door closed during operation
- Replace the filters on a regular basis.

Important Safety Instructions and Save these Instructions.

- The inverter system/rack can reach hazardous leakage currents. Earthing must be carried out prior energizing the system. Earthing shall be made according to local regulations.
- Prior to any work conducted to a system/unit make sure that AC input voltage and DC input voltage is disconnected.
- **CAUTION** – Risk of electric shock. Capacitors store hazardous energy. Do not remove cover until 5 minutes after disconnecting all sources of supply.
- **CAUTION** – Disconnection of the DC source is required to de-energize this unit before servicing.
- Maximum operating ambient temperature is 40° C (104° F).
- AC and DC circuits shall be terminated with no voltage / power applied.
- Some components and terminals carry high voltage during operation. Contact may result in fatal injury.
- Warning labels must not be removed.
- Never wear metallic objects such as rings, watches, bracelets during installation, service and maintenance of the product.
- Insulated tools must be used at all times when working with live systems.
- When handling the system/units pay attention to sharp edges.
- ESD Strap must be worn when handling PCBs and open units.
- The inverter system/rack is not supplied with internal disconnect devices on input nor output.
- REG systems can be seen as independent power sources. To comply with local and international safety standards the output Neutral and PE are bonded internally in the module.
- By-Pass system that have no AC input wired and connected to comply with local and international safety standards N (output) and PE shall be bonded. The bonded between N output and PE must be removed once the AC input is being connected.

* These instructions are valid for most CE+T Products/Systems. Some points might however not be valid for the product described in this manual.

- The safety standard IEC/EN62040-1 requires that, in case of output short circuit, the inverter must disconnect in maximum 5 seconds. However, if the parameter is set at a value > 5 seconds, an external protection must be provided in order that the short circuit protection operates within 5 seconds. Default setting is 60s.
- The equipment must be installed and commissioned by skilled technicians according to instructions in this manual.
- Local regulations must be adhered.
- The manufacturer declines all responsibilities if equipment is not installed, used or operated according to the instructions herein by skilled technicians according to local safety regulations.
- Warranty does not apply if the product is not installed, used and handled according to the instructions in the manuals.
- CE+T cannot be held responsible for disposal of the Inverter system and therefore the customer must segregate and dispose the materials which are potentially harmful to the environment, in accordance with the local regulations in force in the country of installation.
- If the equipment is dismantled, to dispose of the products it consists of, you must stick to the local regulations in force in the country of destination and in any case avoid causing any kind of pollution.
- System is designed for installation in an IP20 or IP21 environment. When installed in a dusty or humid environment, appropriate measures (air filtering ...) must be taken.
- All illustrations in the manual are for general reference, Refer to the technical drawing which is received along with the system for exact information.

3.1 Handling

- The cabinet shall not be lifted using lifting eyes.
- Remove weight from the cabinet by unplugging the inverters. Mark inverters clearly with shelf and position for correct. This is especially important in three phase configurations.
- Empty inverter positions must not be left open. Replace with module or cover.

3.2 Surge and transients

The mains (AC) supply of the modular inverter system shall be fitted with suitable Lightning surge suppression and Transient voltage surge suppression for the application at hand. Manufacturer's recommendations of installation shall be adhered. It is advisory to select device with alarm relay for function failure.

Indoor sites are considered to have a working lightning surge suppression device in service.

- Indoor sites: Min Class II.
- Outdoor sites: Min Class I + Class II or combined Class I+II.


3.3 Other

- Isolation test must not be performed without instructions from the manufacturer.

To download the latest documentation and software, please visit our website at www.cet-power.com

4. Description

e-one 3 - 48/230 is a standalone compact inverter providing a pure sine wave of 230 Vac from 48 Vdc input and deliver output power up to 350 VA. It has an IEC Socket at rear and protected with a fuse.



4.1 Typical load

- Resistive
- Inductive and resistive
- Capacitive and resistive
- Non linear load with a maximum crest factor of 2.5 : 1

4.2 Module Specifications:

| General | |
|---|--|
| Part Number | T551730111 |
| Cooling | Natural Cooling |
| MTBF | 620 000 hours |
| Peak Efficiency DC/AC | > 90% |
| Dielectric strength DC/AC | 3800 Vdc |
| RoHS | Compliant |
| Vibration | GR63 office vibration 0 to 100 hz-0.1 g / transport vibration 5-100 Hz 0.5 g 100 to 500 hz-1.5 g / Drop test |
| Altitude above sea without de-rating | < 1500 m / de-rating > 1500 m – 0.8 % per 100 m |
| Ambient / storage temperature / relative humidity | -20 to 65° C / -40 to 70° C / 95 %, non-condensing De-rating from 45° C to 65° C |
| Material (casing) | Aluminium & Coated steel |
| AC Output Power | |
| Nominal Output power (VA) / (W) | 350 VA / 300 W |
| Short time overload capacity | 150 % (15 seconds within T° range) |
| Admissible load power factor | 0 lagging to 0 leading |


| DC Input Specifications | |
|--|--|
| Nominal voltage (DC) | 48 V |
| Voltage range (DC) | 40 - 60 V |
| Nominal current at 300 W / 48 VDC | 7 A |
| Maximum input current (for 15 seconds) | 11 A |
| Voltage ripple | 2 mV psopho @ 48 V - 80% LOAD |
| AC Output Specifications | |
| Nominal voltage (AC) | 230 V |
| Frequency / frequency accuracy | 50 Hz / $\pm 0.2\%$ |
| Total harmonic distortion (resistive load) | < 3 % |
| Turn on delay | 20 s |
| Nominal current. Protected against reverse current | 1.6 A at 230 VAC |
| Crest factor at nominal power | 2.5 : 1 |
| Short circuit current duration | > 3.2 A for 200 ms, then inverter stops and needs a manual restart |
| Signalling & Supervision | |
| Display | Front LED |
| Alarms output / supervision | Dry contact on the rear |
| Remote ON / OFF | On the rear |
| Standard Compliances | |
| Standards | IEC62040-1 |
| | ETS 300 386 – 2 : 2 mV |
| | EN 55022 / 55032 Class A Radiated and Conducted |
| | ETS 300 132 – 2 : Product Standard |
| | EN61000-4-2 ESD criteria A - 15 kV Air and 8 kV contact |
| | EN61000-4-3 RF Field – Enclosure Port criteria A : 10 V/m |
| | EN61000-4-4 Burst - All ports criteria A : 2kV |
| | EN61000-4-5 Surge criteria B all ports |
| | EN61000-4-6 conducted RF criteria A 10V |
| EN61000-4-8 PFMF criteria A 30 A/m | |

5. Installation

System is designed for installation in an IP20 or IP21 environment. When installed in a dusty or humid environment, appropriate measures (air filtering ...) must be taken.

The e-one is foreseen to be recessed into an electrical cabinet of 19" and 1U height standard or wall mounted. Product weight is 2 kg (4.4 lbs).

5.1 e-one dimensions



For more information on module dimensions, refer to section 12.2, page 24.


5.1.1 Mounting Kit

Make sure that you have received the right accessories for e-one.

5.1.1.1 Desk / Wall Mounting Procedure:

Step 1: Place the module on the desk or place it in the wall.

Step 2: Fix the module with M5 screws on all four sides as shown below.



5.1.2 19-Inch Sub-rack

The 19-inch Sub-rack is specially designed and can accommodate a maximum of two e-one 3 - 48/230 modules. The part number is **T559000004**. The following accessories are present in the 19-inch rack kit.


1 x 19-inch Sub-rack 2 x Sub-rack fixing clamps 8 x M3 Flat head screws of 6 mm length
8 x M5 Nuts 4 x (M6 Philips screws, Flat washers, Spring washers and Cage nuts)

5.1.2.1 Installing 19-inch Sub-rack in the Cabinet

Step 1: Fix the clamp on both sides of the sub-rack using M3 flat head screws.

Step 2: Fix the required modules in the sub-rack (refer the following section 5.1.2.2, page 12).

Step 3: Place the assembled sub-rack in the cabinet and fix it with M6 Philips screws, flat washers, spring washers and cage nuts.




5.1.2.2 Installing module in the 19-inch Sub-rack

Step 1: Choose a slot in the Sub-rack and place the module on the four studs.

Step 2: Fix the module with M5 nuts on all four sides, as shown below.

Step 3: Perform the above processes for fixing the second module in another slot of the sub-rack.



5.2 Wiring

Caution:

The e-one has internal fuses on DC inputs.

Those device do not protect the upstream cables connected to DC inputs and upstream breakers or fuses shall be set up in accordance with DC wires ratings, to meet the local national electrical code standard.


All breakers, cables and wires should be classified for min 90°C (194°F) operation. Matching respectively Line / Neutral feeder to Line / neutral input connections is required.

Before any intervention on the e-one input, operator has to make sure that power is switched off on DC leads.

Some safety labels are stuck on the e-one. They must not be removed.

The insulation cover of conductors must meet the local and international standards and the cross section must be related to the upstream protections.

5.2.1 REG Model - Termination Details



In e-one REG models:


- DC conductors connected to screw terminals must be tied with torque between 1.2 and 1.5 Nm.
- Ground conductors connected to copper plates with bolts must be tied with torque between 5 and 7 Nm.


5.2.2 DC Input connection

Integrator must provide branch circuit protection with breaking capacity related to short circuit capacity of upstream DC source.

- DC Breaker must be installed close enough to permit easy “Break Before Make”.
- Appropriate type can be chosen within the table here below.
- e-one is supplied with safety labels, which must be applied to the breaker in a visible way.

The insulation cover of connecting cables must meet the local and international standards and the cross section related to the upstream protections.

|  | Model | DC input current at 40 Vdc | DC breaker Recommended | Cable size | Max size |
|---|------------------|----------------------------|------------------------|---------------------|----------------------------------|
| | e-one 3 - 48/230 | 9 A | 16 A | 2.5 mm ² | 1 x 2.5 mm ² per pole |



The +DC 48V supply could be earthed or work in float mode.

Adapt the breaking capacity of your breaker in relation to your installation (length cable, battery capacity).

5.2.3 AC Output distribution

The e-one unit has a 1x IEC socket on output.


Note: The output Neutral and PE are bonded internally in the module.

Caution:

The e-one should be turned OFF by remote ON/OFF action. Prior any intervention on AC output make sure DC input has been actually disconnected or, no output voltage is present.

Prior any handling of the e-one, wait a few minutes (minimum 5 minutes) for complete discharge of internal capacitors that have been energized.

Output on socket

|  | Model | Iout @ 230 Vac | Cable size | Max size |
|---|------------------|----------------|---------------------|---------------------|
| | e-one 3 - 48/230 | 1.52 A | 1.5 mm ² | 2.5 mm ² |

Output Short-Circuit

On output short-circuit, the e-one will push more than 3.2 Amps AC current through the output terminals for 200 ms, and then output stops permanently with a continuous RED indication. So, the module stops after 200 ms of short-circuiting.

Output on IEC socket

IEC output is protected by 3.15 amps fuse (5 x 20 mm).

Remark: e-one without static transfer switch function (REG type) can be seen as independent power sources.

5.2.4 Replacing Fuse


In-case Fuse failure, perform the following steps to replace fuse.

Fuse Details:

| Manufacturer | Manufacturer Part Number | Current Rating | Voltage Rating AC | Fuse Size/Group |
|--------------|--------------------------|----------------|-------------------|-----------------|
| Schurter | 0001.2509 | 3.15 A | 250 Vac | 5 mm x 20 mm |


Fuse will be present at rear side of the system.

- Step 1.** By using the Flat Screw Driver gently turn the Fuse holder to 45° in anti clock wise direction. The Fuse Holder automatically ejects from the slot. (Fuse holder will not go beyond 45°).
- Step 2.** Remove the Fuse holder from the slot.
- Step 3.** Replace the appropriate new Fuse in the holder.
- Step 4.** Place the Fuse with holder in the slot.
- Step 5.** By using the Flat Screw Driver gently push and turn the Fuse holder to 45° in clock wise direction. Make sure Fuse holder is locked.




Warning: Risk of electric shock, do not replace the Fuse in system running condition.

5.2.5 Grounding

Earth connection must be done to the point referenced with symbol . Input ground must be connected to the appropriate terminal

Caution: Current leakages can reach hazardous values. For your personal, SAFETY earth connections must be done before energizing the system.



5.2.6 Remote Monitoring and Control

5.2.6.1 Alarm Connector

There is one free potential changeover contact provided. Maximum wire size is 0.5 mm². It can be used for Alarm indication purposes. It has one Major Alarm relay.


N.B. : Relays are energized while idle (i.e. relays de-energized when event occur).

MAJOR relay provide an open or close free potential contact



Relay characteristics:

- Maximum switching capacity: 1 A @ 60 VDC
- Maximum switching power: 30 W



5.2.6.2 Remote ON/OFF

e-one system can be remotely activated or stopped (stand-by mode).



Changeover contacts must be used.

The voltage present on terminal 1 and 3 is +12 V (galvanically insulated). Care should be taken to avoid connecting any external voltage on terminal 1 to 3. Maximum wire size is 1 mm²

Functional table for remote ON/OFF function

| States | Pin 1-3 | Pin 2-3 | System status |
|--------|---------|---------|--------------------------------|
| 1 | Open | Open | System working normally |
| 2 | Closed | Open | Output switched OFF LED OFF |
| 3 | Open | Closed | System working normally |
| 4 | Closed | Closed | Output switched OFF LED OFF |

The 3 wires must be used for the redundancy on the remote ON/OFF. Use NO/NC relay contact.

6. Getting started

6.1 Starting procedure

1. Check the DC power supply (within range).
2. Turn on the DC breaker to the module. (Wait at least 30 seconds until INFO LED turns solid green).
3. Check AC output voltage at IEC socket.
4. Check that system is operating under normal conditions.

6.2 LED indication- Alarm status

e-one module indicate its functional status through module front **INFO LED**.



| S. NO | INFO LED | Description | Alarm |
|-------|---------------------|---|-------|
| 1 | OFF | No Output | ✓ |
| 2 | Permanent GREEN | Working Fine | - |
| 3 | Blinking GREEN | DC Source Out-of-range | ✓ |
| 4 | Blinking ORANGE | Output Power / VA De-rating | - |
| 5 | Slow - Blinking RED | Short-circuit Sequence | - |
| 6 | Fast - Blinking RED | Module Over-Temperature and Output OFF | ✓ |
| 7 | Permanent RED | Output OFF due to Permanent Short-Circuit | ✓ |
| 8 | Blinking RED- GREEN | Load Power too High and Output OFF | ✓ |

7. Finishing

1. Make sure that the inverter is properly fixed.
2. Make sure that the inverter is connected to Ground.
3. Make sure that DC upstream breaker is switched OFF.
4. Make sure that all cables are according to recommendations and local regulations.
5. Make sure that all cables are strained relieved.
6. Make sure that the Remote ON/OFF is appropriately wired.
7. Re tighten all electrical terminations.
8. Make sure that DC polarity is according to marking.
9. Switch ON DC breaker.

Inverter starts and delivers AC output voltage.

8. Disassembly & Disposal

8.1 Disassembly

Switch off the upstream and downstream protective elements to stop the function of Inverter system.

- Disconnect the wires from the terminals.
- Ensure that all the cables (including PE, communication, etc) are removed.
- Check that all the cables are moved away from the system.
- Unscrew the system from the mounting position.
- Dismantle the system completely and segregate the materials.
 - Enclosure & accessories.
 - Cables.
 - Wound components.
 - PCBA etc.

8.2 Disposal

CE+T cannot be held responsible for disposal of the Inverter system and therefore the customer must segregate and dispose the materials which are potentially harmful to the environment, in accordance with the local regulations in force in the country of installation.

If the equipment is dismantled, to dispose of the products it consists of, you must stick to the local regulations in force in the country of destination and in any case avoid causing any kind of pollution.

9. Commissioning

The DC breaker is a protection device. When modules are plugged in a system please make sure the corresponding DC breaker is engaged in the ON position. Failure to observe this rules will result not to have all module operating when running on DC.

Installation and commissioning must be done and conducted by trained people fully authorized to act on installation.

It is prohibited to perform any isolation test without instruction from manufacturer.

Equipments are not cover by warranty if procedures are not respected.

9.1 Check list

| DATA | |
|--|----------|
| Date | |
| Performed by | |
| Site | |
| Inverter serial number | |
| | |
| | |
| | |
| | |
| | |
| ACTION | OK/ N.OK |
| Check the DC power supply and switch ON the DC breakers | |
| Check if inverters are working properly (INFO LED Green) | |
| Check output voltage | |
| Check if system has no alarm | |
| Switch OFF the system | |
| Test on load (if available) | |


10. Trouble shooting and Defective modules

10.1 Trouble shooting

| | |
|--------------------------------|--|
| Inverter does not power up: | <p>Check the DC terminals are properly connected and also ensure the polarity.</p> <p>Check DC input is in range and DC breaker is switched ON (DC breakers)</p> <p>Check for loose terminations</p> |
| Inverter does not start: | <p>Check front ON/OFF button and Remote ON/OFF terminal</p> |
| Inverter only run on AC or DC: | <p>Check the Voltage range for DC.</p> |
| No output power: | <p>Check output breaker</p> |

10.2 Defective Modules

- A repair request should follow the regular logistics chain:
End-user => Distributor => CE+T Power.
- Before returning a defective product, a RMA number must be requested through the <http://my.cet-power.com> extranet. Repair registering guidelines may be requested by email at repair@cet-power.com.
- The RMA number should be mentioned on all shipping documents related to the repair.
- Be aware that products shipped back to CE+T Power without being registered first will not be treated with high priority! (Label shown here is only for representation)



11. Service and Maintenance Task

11.1 Service

For Service

- Check Service Level Agreement (SLA) of your vendor. Most of the time they provide assistance on call with integrated service. If such SLA is in place, you must call their assistance first.
- If your vendor doesn't provide such assistance (*) you may contact CE+T through email: customer.support@cet-power.com

(*) CE+T will redirect your call to your vendor if he has such SLA in place.

11.2 Maintenance Task

Maintenance task should be performed only by trained personnel with sufficient knowledge on the product.

Manual check


- Validate DC input and AC output voltage with multi-meter
- Replace dust filter (if present)
- Take a snap shot of the inverter

Optional

- With an infrared camera check termination hot spots
 - Tighten terminations


12. Appendix

12.1 e-one 3 - 48/230V - Wiring diagram




12.2 e-one 3 - 48/230 - Dimensions


12.2.1 Module




Front View



Left View




Top View




All dimensions are in mm


12.2.2 19-Inch Sub-rack




Front View



Left View



Top View



All dimensions are in mm

